

PASSCODE MONITOR- SETTINGS

The following instructions will outline how to turn ON/OFF the PASSCODE SECURITY Settings

Your monitor has many unique settings. The following will share how to use the PASSCODE SECURITY settings and well as turn this feature on and off.



STEP 1 – Press and hold **M (MODE)** Button until screen turns to either MAX speed or AVE speed




STEP 2 Press and hold **+ - (UP/Down)**

Simultaneously for 2-4 seconds until screen flashes and goes to setting interface. You have 4 settings

Use the **+ -** to toggle thru each screen and the **M** to move to the next setting

Scroll thru the settings until you get to "passcode" –at this point you can either set your code- NOTE please write this down and remember this. Your monitor can be reprogramed but it will require speaking to an agent. If you do not want this feature simple turn it off. You do this by moving the **+ -** to your desired preference. Press the **M** button to return to the main screen



Please perform a safety check and make sure to adjust your MAX speed to a comfortable and confident speed. Enjoy the Ride

Please let us know if you have any comments and/or follow up questions!

CS@BIKE.com or 1-877-755-2453(BIKE)

