

BATTERY INSERTING



STEP 1- Inspect Check
-Battery connector slots
-Bike Frame connectors within battery chamber

STEP 2- Insert Battery
Grab battery with hand on indentation and lift and place bottom of battery in middle of chamber and slide down onto the frame/battery connectors

KEY DOES NOT NEED TO BE ENGAGED



STEP 3 – Engage Battery
Press firmly at top of battery until a **CLICK/ENGAGEMENT** is heard

Check battery is firmly engaged

Please let us know if you have any comments and/or follow up questions!

CS@BIKE.com or 1-877-755-2453(BIKE)

